

Patent Application

for

SYSTEM AND METHOD FOR AUTOMATIC GAIN AND SLOPE
EQUALIZATION PROVISIONING OF TELEPHONE TRANSMISSION LINES

by

James E. Sclater

&

William V. Miller, III

Field of the Invention

[0001] The present invention is related to systems and methods for provisioning telephone circuits. More particularly, the present invention is related to a system and method for automatically compensating for gain and frequency response impairments in telephone transmission lines.

Background of the Invention

[0002] The process of adjusting gain and frequency response to compensate for impairments in a telephone transmission line is referred to as alignment. There are existing technologies which automate the alignment process to some extent; however, these generally require the use of specialized test equipment, and must be performed by a service technician from the customer site. One such channel unit "auto-alignment" technology offered requires that a service technician travel to the customer site, disconnect the customer equipment and connect a Transmission Impairment Measurement Set (TMS), or equivalent test equipment, to the transmission line. The

service technician must then complete a complicated nine-step process to properly align the channel-unit. In the event that the channel-unit should need to be replaced, or the alignment repeated for some other reason, the service technician must return to the customer site and repeat the entire process.

[0003] This nine-step alignment process employs an in-band signaling approach in which the TIMS is configured to send command tones at specific frequencies toward the channel unit from the customer site. These command tones instruct the unit as to which phase of the alignment process is to be performed. Command acknowledgment tones are sent back from the channel unit toward the service technician. A series of single-frequency tones at 404 Hz, 1004 Hz and 2804 Hz are sent toward the channel unit one at a time from the TIMS by the service technician during the alignment process. These three tones are evaluated on an individual basis in order to determine the gain and frequency response correction parameters.

Summary of the Invention

[0004] The above limitations are overcome, and other advantages are realized by providing a digital carrier based channel unit system that provides automatic gain and frequency response correction for twisted-pair transmission line impairments in both transmit and receive directions. In a preferred embodiment, the system consists of two devices, namely a metallic interface unit and a calibration unit. The metallic interface unit is a foreign-exchange station-end unit which is installed in a digital carrier channel bank at either an end-office or a remote-terminal location. The calibration unit is a "passive" line-powered device which is installed at the network interface of the customer premises location. The calibration unit is passive in that it is powered by the metallic interface unit, but does not interfere with the operation of the customer premises equipment, or the quality of transmission between the metallic interface unit and customer equipment under normal operating conditions.

[0005] The metallic interface unit and calibration unit system is a significant improvement over the current state of auto-alignment technology in that it truly automates that alignment process, does not require the use of special equipment, and

may be performed at any time without making unnecessary trips to the customer site. The calibration unit is installed at the customer site at the same time that phone service is connected to the customer premises equipment. The auto-alignment sequence can be initiated from the customer site at the press of a button on the calibration unit with the metallic interface unit installed in the channel bank at the end-office or remote-terminal location. A unique signature current is used by the calibration unit to signal a request to the metallic interface unit to begin the auto-alignment sequence. The auto-alignment sequence may also be activated from the metallic interface unit simply by installing it in the channel-bank, or by setting its operating mode selection switch to the "AUTO ALIGN" position if already installed. Auto-alignment may be repeated at any time, without traveling to the customer location, by turning a switch or re-installing the metallic interface unit in the channel-bank.

[0006] Signaling from the metallic interface unit to the calibration unit is carried out using an advantageous out-of-band signaling method in which unique sequences of open and closed battery intervals are used to relay specific commands. The design of the calibration unit allows it to continue to operate even when its power source is removed during these signaling sequences. When directed by the metallic interface unit, the calibration unit disconnects the customer premises equipment tip and ring connections, and transmits a composite multi-tone test signal towards the metallic interface unit. The composite test signal is a square wave of known amplitude, consisting of a 1kHz fundamental Fourier component and its odd harmonics. The relative amplitude of each harmonic is related through Fourier analysis to that of the fundamental by a factor of $(1/n)$, where n is the order of the harmonic. The metallic interface unit filters the received composite test signal, analyzes the 1kHz fundamental and 3kHz harmonic components via a Discrete Fourier Transform based algorithm, and automatically adjusts the overall gain and frequency response characteristics of its two-wire side transceiver to compensate for impairments in the twisted-pair transmission line in both transmit and receive directions. Following the determination of a gain and slope solution, the metallic interface unit sends a second

instruction to the calibration unit, commanding it to again disconnect the customer premises equipment tip and ring connections and apply a 900-ohm + 2.15 uF quiet-termination. The metallic interface unit then measures C-Message weighted idle-channel noise on the twisted pair circuit. Should the result of the measurement indicate that the noise level exceeds a nominal threshold of 32 dBmC0, the metallic interface unit notifies the service technician by flashing an LED on the front-panel of the metallic interface unit. This noise measurement feature further automates the circuit setup process in that the service technician need not travel to the customer site to perform the line-qualification with specialized test equipment.

[0007] The metallic interface unit also employs an adaptive echo-cancellation technology to compensate for impedance mismatch presented to its two-wire side by the customer equipment load, as transformed through the transmission line. The combination of automatic gain and frequency response correction technology with adaptive echo-cancellation simplifies circuit provisioning by eliminating the manual adjustment of option switches that set gain, slope equalization, and both compromise and precision balance networks. In some instances, up to forty-two manual adjustments may be eliminated. By reducing the number of options that must be set manually, the possibility for human error is also reduced, thereby increasing the accuracy in provisioning a circuit. In addition, the need for qualifying individual loop-plants in order to determine appropriate manual option settings prior to turn-up is eliminated, as the qualification is performed automatically by the metallic interface unit and calibration unit. The metallic interface unit and calibration unit benefits telephone companies, as well as the end consumer, by reducing both the time and labor costs associated with turning-up a telephone circuit, providing for consistent voice-channel quality, and optimizing performance on an individual loop-plant basis.

Brief Description of the Drawings

[0008] Other objects and features of the present invention will become apparent from the following detailed description considered in connection with the accompanying drawings that disclose a preferred embodiment of the present

invention. It should be understood, however, that the drawings are designed for the purpose of illustration only and not as a definition of the limits of the invention.

[0009] In the drawings, wherein similar reference characters denote similar elements throughout the several views:

[0010] Figure 1 is a block diagram of an embodiment of the present invention;

[0011] Figure 2 is an illustration of the calibration unit installed in an office building setting;

[0012] Figure 3 is an illustration of the calibration unit installed in a typical residential home;

[0013] Figure 4 is an illustration of the metallic interface unit and calibration unit installed in various types of telephone circuits;

[0014] Figure 5 is a simplified block diagram of an embodiment of the calibration unit;

[0015] Figure 6 is a circuit diagram of an embodiment of the calibration unit;

[0016] Figure 7 is a state diagram illustrating the functionality of the calibration unit microcontroller;

[0017] Figure 8 is a block diagram of an embodiment of the metallic interface unit;

[0018] Figure 9 is a state diagram illustrating the functionality of the metallic interface unit microcontroller auto-alignment feature; and

[0019] Figures 10a and 10b illustrate out of band command sequences exchanged between the metallic interface unit and the calibration unit.

Detailed Description of the Invention

[0020] Referring to the drawings, Figure 1 is a block diagram of a system according to a preferred embodiment of the present invention. Customer Premises Equipment (CPE) 10 is typically connected to the telephone company at a network interface 12 at the customer's location. According to an embodiment of the present invention, the CPE 10 is connected to a calibration unit 14 at the network interface 12. The calibration unit 14 is in turn connected to the copper pair 16 leading to a channel

unit. Channel units are well known in the art of telephone networks, and perform the function of converting analog signals from a telephone line on the copper pair 16 into digital signals which can be transmitted to and from the telephone network 20 over a digital carrier, such as a T1 line 22. However, according to a preferred embodiment of the present invention, the channel unit is a metallic interface unit 18 which is specially designed to interact with the calibration unit 14 installed at the customer location, in addition to performing the usual functions of a channel unit.

[0021] Figure 2 shows a typical application of the calibration unit in an office building 24. An equipment room 26 preferably may contain a plurality of calibration units 14, each connected to an individual phone extension 28 within the office 30. The calibration units 14 are each connected to a corresponding metallic interface unit device (not shown), which could be arranged conveniently in, for example, a bank of metallic interface channel units at a central location.

[0022] Figure 3 shows a typical residential application of a system according to the present invention. The calibration unit 14 is installed between the copper pair 16 entering the home, and the CPE 10 installed within the home. Of course, those of ordinary skill in the art will readily recognize that many other arrangements of the calibration unit 14 and metallic interface unit 18 pair are possible within various telephone network configurations, as shown in Figure 4. In general, the calibration unit 14 and metallic interface unit 18 are located at opposite ends of an individual copper pair, with the calibration unit 14 located at the customer end of the copper pair.

[0023] In practice, the calibration unit 14 temporarily disconnects the CPE 10 from the copper pair 16, and transmits a test tone over the copper pair 16 which is received by the metallic interface unit 18. The metallic interface unit 18 analyzes the received test tone and determines the transmit and receive attenuation, and slope equalization required to deliver a -3.5 dBm level at 1 kHz into a 900 ohm +2.15 uF termination at the network interface 12 of the CPE 10. The metallic interface unit thereafter compensates for frequency dependent impairments in the line by applying the determined gain and slope equalization to the line. The process of measuring line

impairments and compensating for the impairments is known as auto-alignment. Conveniently, the auto-alignment sequence can be initiated from either the metallic interface unit 18 or the calibration unit 14. Once the auto-alignment sequence has been completed, the calibration unit re-connects the CPE 10 to the copper pair 16.

Calibration Unit

[0024] Fig. 5 is a block diagram of the calibration unit 14. Tip 32 and ring 34 connections are provided at the telephone network side of the calibration unit 14. Tip 36 and ring 38 connections are also provided at the CPE 10 side of the calibration unit 14. The calibration unit 14 is provided with a relay 40 for connecting or disconnecting the CPE 10 from a telephone network. The calibration unit is also provided with a tone generator 42 for transmitting tones over the copper pair back toward the metallic interface unit 18. A controller 44 is provided for controlling the operation of the calibration unit's 14 various functions. The calibration unit includes a relay driver 46 as well an indicator LED 48. There is also a power supply 50 and a push button control 52 provided.

[0025] Fig. 6 is a detailed circuit diagram of a preferred embodiment of the calibration unit 14. The calibration unit is provided with a network interface connector 54 for connecting CPE 10 (not shown) to the calibration unit 14. A relay coil 56 is provided for controlling relay contacts 58 for connecting or disconnecting the CPE 10. Relay coil 56 is energized by transistor 58, which is turned on or off by the microcontroller 60 via relay control line 62. An indicator LED 64 is also controlled by the microcontroller 60 by turning on or off transistor 66 via control line 68. The current path when the transistor 66 is turned on is through the relay coil 56 through the LED 64 and through the control transistor 66 so that the relay 56 is always energized when the LED 64 is being illuminated. Relay coil 56 may then be energized with the LED 64 turned off via control line 62, or with the LED 64 turned on via control line 68.

[0026] The preferred embodiment of the calibration unit 14 further comprises surge protecting means 70 for protecting the calibration unit 14 circuitry from surges

occurring on the tip or ring leads. The calibration unit 14 also has DC rectifying means, shown generally at 72. The calibration unit 14 is provided with a push button switch 74, which once pushed, activates a current source circuit 76, which in turn sinks current from the tip lead 114 and/or frame ground (FGND) lead via the rectifier bridge 72 toward the ring lead 116. The tip 114 and ring 116 leads are connected to the telephone network, and in particular to the tip and ring leads of the metallic interface unit (not shown). The frame ground lead (FGND) is connected to earth-ground, which is the reference ground for the telephone network, as is the frame ground (FGND) lead of the metallic interface unit (not shown). In this manner an out of band signaling means is provided between the calibration unit 14 and the metallic interface unit. The metallic interface unit is provided with logic to recognize the current sinking condition caused when push button 74 is depressed. Thus, if push button 74 is depressed for a predetermined length of time, between five and ten seconds for instance, the metallic interface unit recognizes this as a command to begin the auto-alignment process initiated from the calibration unit.

[0027] The auto-alignment sequence can also be initiated from the metallic interface unit by transmitting a special out-of-band signaling sequence over the tip and ring leads from the metallic interface unit to the calibration unit 14, which is received at the microcontroller 60 through input port 80 on "Signal In" line 82.

[0028] The out-of-band signaling sequence from the metallic interface unit to the calibration unit will now be described in further detail. When the metallic interface unit needs to remotely signal the calibration unit to begin the auto-alignment sequence, the metallic interface unit applies a predetermined series of alternating voltage changes to the tip and ring leads. These voltages are alternating open and closed battery intervals applied at a frequency which is below audible frequencies, such as, for instance 5 (five) Hz, and at a specific duty cycle such as 24%. A command which instructs the calibration unit to begin the auto-alignment sequence may comprise for instance 13 alternations between a high and low voltage followed by, for example a one half-second pause followed by another 13 alternations between high and low voltages. When a closed battery interval is received at the calibration

unit tip 114 and ring 116 leads , the output 78 of rectifier 72 turns on a current source shown generally at 84 in turn driving current through resistors 86, 88 and 90, and turning on FET 92 thereby driving the voltage at "Signal-In" line 82 and hence input port 80 to logic-zero level for the duration of the signal interval. Transistors 94 and 96 are also turned on during receipt of a high voltage signal from the metallic interface unit, causing power supply capacitor 98 to fully charge. Power supply capacitor 98 stores energy which is used to supply power to the microcontroller 60 through power supply port 100. Zener diode 102 ensures that the power supply capacitor 98 is charged to the appropriate voltage to supply power to the microcontroller 60 through power-supply port 100.

[0029] Once the microcontroller 60 recognizes the appropriate signaling sequence at input port 80, a boost circuit is turned on through boost line 104. The boost signal over boost line 104 turns on FET 106 which in turn activates transistor 108, increasing the current delivered to power-supply capacitor 98 and power-supply port 100 of the microcontroller 60.

[0030] The microcontroller 60 is programmed such that when the controller receives the appropriate signaling sequence through input port 80 commanding the calibration unit 14 to begin the auto-alignment procedure, the controller produces a test tone signal at port 106 which is transmitted over the tip and ring leads toward the metallic interface unit (not shown). The controller is programmed to produce a 1kHz square-wave signal. The 1kHz square-wave signal is applied to output signal line 110, coupled through transformer 112 and relay contacts 58 and finally onto tip 114 and ring 116 leads which are connected to the metallic interface unit through the copper pair (not shown).

[0031] Turning to Fig. 7, the functionality of the microcontroller 60 of the calibration unit will now be described. The calibration unit starts in an "idle sequence" 200. While in the idle sequence, the current boost line 104 remains low, so that the current boost circuit remains off. Also, the relay 56 and the LED 64 are not energized, and the tone output 110 remains low. If the Auto-Align sequence is initiated, either from push-button 74 or from receiving the Auto-Align Initiate

command from the metallic interface unit through the out-of-band signaling described above, or if the Auto-Align Passed command is received, the calibration unit microcontroller 60 enters a "relay on sequence" 202. While in the relay on sequence, the boost circuit is turned on through boost line 104. This draws the current necessary to run the calibration unit during the following processes. Also, the relay 56 is energized, but LED 64 remains off. Also, during this sequence, the tone-out 110 remains low.

[0032] Once the microcontroller 60 has been in the "relay on sequence" 202 for more than 500ms, it moves to either the "LED on sequence" 204 or the "flash sequence," 206, 208 depending on which command was received. If the "Auto-Align Passed" command was received, the microcontroller 60 enters the "LED on sequence" 204. In this sequence the boost circuit remains on, the relay 56 remains energized, and the LED 64 is turned on. Also, the tone out line 110 remains low. After 30 seconds in the LED on sequence 206, the calibration unit microcontroller returns to the idle sequence 200.

[0033] If the "Initiate Auto Align" commands was received, the microcontroller moves from the "relay on" sequence 202 to the "flash sequence" 206, 208. During the "flash sequence," the microcontroller flashes the LED 64 on and off for 25ms intervals. The relay 56 remains energized throughout the "flash sequence"; control port 62 is activated when control port 68 is deactivated, and vice-versa so that the relay 56 remains energized while the LED 64 is switched on and off. The current boost 104 remains high throughout the flash sequence and the tone out line 110 remains low.

[0034] After the microcontroller 60 has been in the flash sequence for 3 seconds, the "tone sequence" 210, 212 begins. During the tone sequence 210, 212, the boost line 104 remains high, providing current to run the calibration unit. Also, the relay 56 remains energized and the LED 64 remains off. The tone out line 110 alternates between high and low for 500us intervals, generating a 1 kHz square wave signal, which lasts at least one second. Once the tone sequence 210, 212 is complete, the calibration unit microcontroller returns to the idle sequence 200.

Metallic Interface Unit

[0035] Fig. 8 illustrates a block diagram of the metallic interface unit 18. The metallic interface unit 18 is provided with tip 118 and ring 120 ports connected to the copper pair leading from the calibration unit (not shown). Maintenance Access Connector (MAC) ports 122 are provided. A SLIC 124 provides an interface between the subscriber side tip 118 and ring 120 leads and the encoder/decoder (CODEC) 126, 128 circuits by way of the dual digital-to-analog converter (DAC) 130. The dual DAC 130 is provided with Tx and Rx attenuators 132, 134. The metallic interface unit 18 is also provided with a Rx line equalizer 136. The SLIC and external circuitry synthesize two-wire impedance set to 900 ohm and 2.15 uF. The SLIC 124 provides internal loop and ground key detectors which are monitored by the micro controller 138. The SLIC 124 also provides battery reversal and typical conditions for line side answer supervision and ground start applications, and controls the application of ringing. The SLIC 124 is also used in conjunction with a shorting circuit across tip 118 and ring 120 to send coded out-of-band command sequences (described above), consisting of open battery intervals, to the calibration unit (not shown) in order to command the calibration unit to begin the auto-alignment sequence.

[0036] The dual DAC 130 sets attenuation in both transmit and received directions. Each 8 bit DAC 132, 134 is configured by the microcontroller 138 to provide between 0 and 16.5 dB of attenuation. The transmit and receive DAC settings are determined by a digital signal processor (DSP) 140 during the auto-alignment sequence.

[0037] In the preferred embodiment, the DSP 140 and the microcontroller 138 communicate with one another via a 16-bit control word and a 16-bit response. The control word includes FM bits that instruct the DSP to perform various functions. The response word includes PQ bits that can indicate the results of a function performed by the DSP. Of course other means of communication between the DSP 140 and the microcontroller 138 could be devised without departing from the spirit of the invention.

[0038] The equalizer 136 provides slope equalization in the receive direction, and is configured by the microcontroller 138. The slope setting is determined by the DSP 140 during the auto-alignment sequence. Slope equalization in the transmit direction is accomplished within the DSP 140.

[0039] A first CODEC 126 provides the analog to digital and digital to analog interface between the analog voice band signals at tip 118 and ring 120, and the DSP 140. The first CODEC 126 receives frame sync timing and 1.544 MHz master clock from the back plane via an ASIC 142 when the channel unit is operating in PCM mode and 2.560 MHz when in PAM mode.

[0040] Digital data exchange between the first CODEC 126 and the DSP 140 represents linearly encoded voice band signals. The ASIC 142 controls PAM and PCM modes of operation according to automatic detection of digital back planes.

[0041] ASIC 142 and CODECs 126, 128 provide an analog-to-digital and digital-to-analog interface between the back plane PAM bus and the DSP 140. The second CODEC 128 receives frame sync timing and 1.544 MHz master clock from the back plane via the ASIC 142 when the channel unit is operating in PCM mode and 2.560 MHz when in PAM mode, and provides the transmit TLP interface (Tx TLP).

[0042] Digital data exchange between the second CODEC 128 and DSP 140 represents linearly encoded voice band signals. The ASIC 142 controls PAM and PCM modes of operation according to automatic detection of the digital back plane.

[0043] During the auto-alignment sequence, the DSP 140 analyzes the test tone received from the calibration unit 14 and determines the proper slope and attenuation setting in the transmit and receive paths to compensate for loss and roll-off introduced by the twisted pair located between the CPE 10 and the metallic interface unit tip 118 and ring 120 ports. As described above, the test tone received from the calibration unit 14 consists of a square wave with a fundamental frequency component of 1 kHz at -8.1 dBm into 900 ohm. The third harmonic at 3 kHz is approximately 9.5 dB below the fundamental as generated by the calibration unit. The DSP 140 determines a slope setting by taking a Discrete Fourier Transform (DFT) of the square wave received from the calibration unit and comparing the relative amplitudes of the 1 kHz

and 3 kHz components. The DSP 140 calculates 5 values: the prescription type 309D slope equalization setting, as well as two user selectable attenuation setting configurations for both the transmit and receive directions; for instance, the user may select either a 3.5 dB EML (Expected Measured Loss) transmit and 0 dB EML receive path loss, or a 5.5 dB EML transmit and 0 dB EML receive path loss. The microcontroller 138 determines which set of attenuation settings to use based on the position of EML option switch 150.

[0044] The microcontroller 138 is connected to the SLIC 124, the dual DAC 130, the DSP 140 and ASIC 142. The microcontroller 138 is also connected to a shift register 144 and a ringing scalar 146. The mode of operation of the metallic interface unit 18 can be altered through rotary mode switch 148 and dip switches 150 which are connected to the microcontroller 138. The auto-alignment sequence may be started by turning rotary mode switch 148 to the "auto-align" position. The metallic interface unit microcontroller 138 is also programmed to initiate the auto-alignment sequence whenever the metallic interface unit is plugged into a channel bank (not shown). Auto-alignment may be repeated at any time, without traveling to the customer location by turning the rotary mode switch 148 to the "auto-align" position or by reinstalling the metallic interface unit 18 into the channel bank. The microcontroller 138 is further provided with logic to recognize an out-of-band signature current drawn by the calibration unit 14 when push button 74 is depressed for the appropriate length of time. Thus, the auto-alignment sequence can be initiated from either the calibration unit side or the metallic interface unit side of the copper pair 16.

[0045] Turning to Fig. 9, the auto-alignment functionality of the microcontroller 138 of the metallic interface unit 18 will now be described. The metallic interface unit begins in the "start" mode 214. During "start", the microcontroller 138 applies battery to the tip and ring and allows time for the energy storage capacitor 98 in the calibration unit 14 to fully charge. The variable "COMPLETE", which indicates the status of the combined gain and slope alignment and idle-channel noise test, is initialized to the value FALSE. The variable "COMMAND" is set to INITIATE, indicating that the instruction to be sent to the calibration unit 14 will cause it to

generate the auto-alignment test signal. Also if the metallic interface unit detects that a closed loop condition exists at the near-end, the variable "LOOP_FLAG" is set to TRUE, otherwise, it is set to FALSE.

[0046] After the metallic interface unit has been in start mode 214 for 5 seconds, it moves to the "send command" state 216. Here, the variables SEQUENCE_COUNT and OPEN_COUNT are initialized by setting both to zero. OPEN_COUNT indicates the number of open-battery intervals that are to be generated during the signaling intervals 218, 220, thereby forming the command to be sent to the calibration unit 14. SEQUENCE_COUNT indicates the number of times that the command represented by OPEN_COUNT has been sent. Next, the microcontroller 138 begins transmitting a command sequence to the calibration unit via the tip 118 and ring 120 leads.

[0047] The command sequence is illustrated at 218, 220 and 222. It begins with an open battery interval 218, which lasts for 48ms. Next, there is a closed battery interval 220 for 150ms, during which OPEN_COUNT is incremented by one. The open interval 218 and closed interval 220 alternate until OPEN_COUNT is equal to COMMAND, which is either 13 for the INITIATE command, or 15 for the PASS command. The INITIATE command is sent to instruct the calibration unit 14 to generate the auto-alignment test signal for gain and slope determination. The PASS command is sent to instruct the calibration unit 14 to apply a quiet-termination at the CPE for idle-channel noise testing, and to illuminate its LED 64 for 30 seconds. For illustrative purposes, only the "Initiate Auto Align" command (COMMAND = 13) will be described. After 13 sets of open and closed intervals 218, 220, the microcontroller enters an inter-sequence step 222, which lasts for 499.5ms. During the inter-sequence step, SEQUENCE_COUNT is incremented and OPEN_COUNT is reset to zero. Next, the open interval 218 and closed interval 220 are repeated 13 more times. When the microcontroller enters the inter-sequence step 222 the second time, SEQUENCE_COUNT is incremented to equal two, causing the microcontroller 138 to enter the "watchdog" state 224.

[0048] Thus, the command sequence (for the “Initiate Auto Align” command) comprises thirteen sets of open and closed intervals, followed by a half second inter-sequence interval, followed by thirteen sets of open and closed intervals. The frequency of the command sequence realized on the tip 118 and ring 120 leads is well below audible frequencies due to the duration of each interval. Furthermore, because the number of open-closed sequences is repeated twice with a pause in between, it is highly unlikely that such an event would ever occur by accident. Thus, when the calibration unit detects the command sequence, there is a high degree of confidence that the command was intended.

[0049] When the watchdog state 224 is entered, a TIMEOUT timer is initialized to zero and begins tracking the elapsed time. If NEW_VALUES equals TRUE (indicating that a gain and slope alignment solution has been determined), the microcontroller enters the “delay” state 225 where TIMEOUT is reinitialized to 30 seconds and the DSP is instructed to break the voice path in the receive direction and send quiet-termination towards the calibration unit 14. After 1 second, the microcontroller enters the “quiet term start” mode 226, and remains there until COMPLETE equals TRUE (indicating that the idle-channel noise test has been run for at least 3 seconds), or “no loop closure” is detected.

[0050] During the “quiet term start” mode 226, the metallic interface unit microcontroller 138 instructs the DSP 140 to measure idle-channel noise. If the loop remains closed for three seconds, the metallic interface unit microcontroller 138 flashes its signaling LEDs (not shown) slowly and sets COMPLETE equal to TRUE to indicate that the auto-alignment process has completed (both a gain and slope solution has been determined and the idle-channel noise test has been completed). The metallic interface unit microcontroller 138 then checks the DSP 140 response PQ for the results of the idle-channel noise test. If the DSP 140 indicates that the noise level exceeded 32 dBmC0 (decibels above reference noise, where the reference noise power is defined as 1 picowatt, with C-Message weighting, at the zero transmission level point), the variable NOISE_FLAG is set to TRUE; otherwise NOISE_FLAG is set to FALSE, causing the FAIL LED on the front panel of the metallic interface unit

to flash in order to indicate that the idle channel circuit noise exceeds 32 dBmC0. If COMPLETE is TRUE, or "no loop closure" is detected, "quiet term finish" mode 227 is entered.

[0051] Within "quiet term finish" 227, the microcontroller instructs the DSP 140 to turn off all options, thereby discontinuing idle-channel noise analysis and restoring the voice-path in both transmit and receive directions. If COMPLETE is FALSE, the "no calibration unit" state 232 is entered; otherwise, if COMPLETE is TRUE and either "no loop closure" is detected or NOISE_FLAG is true or TIMEOUT has reached 30 seconds, the "finish" state 228 is entered. Also, "no calibration unit" 232 can be entered directly from "watchdog" 224 if TIMEOUT reaches 3 seconds, and "no loop closure" is detected, or from "delay" 225 if no loop closure is detected.

[0052] In finish mode 228, the microcontroller causes the LED's to flash rapidly, stops the TIMEOUT timer, and instructs the DSP to standby by setting FM to "WAIT." Next the microcontroller moves to "Exit" 230. Once in "exit" 230, if the rotary switch 148 is not set to "Auto-Align" the metallic interface unit is restarted.

[0053] From the "watchdog" state 224, if the TIMEOUT timer exceeds three seconds and "no loop closure" is detected, then the calibration unit has not been detected, and the "no calibration unit" state 232 is entered. In the "no calibration unit" state 232 the LED's are flashed in an "X" pattern rapidly, and the TIMEOUT timer is stopped. If the microcontroller is in the "no calibration unit" state 232 for more than 10 seconds, or if the rotary switch 148 is not set to "Auto Align" and the auto-alignment sequence was not entered as the result of "Power-On Reset", the exit state 230 is entered.

[0054] From the "watchdog" state 224, if TIMEOUT reaches 3 seconds and NEW_VALUES is FALSE (indicating that the DSP 140 has not yet attempted to determine a gain and slope solution) and "loop closure" is detected, then the "Analyze Tone" state 234 is entered. Entering the "Analyze Tone" state 234 indicates that the calibration unit is present, and that the alignment test signal should be detected. FM is set to "Analyze Tone" to instruct the DSP 140 to analyze the test signal received from the calibration unit 14. When the DSP response PQ is set to "Store Value", the "Store

Values" state 236 is entered. On the other hand, if TIMEOUT reaches 10 seconds, or if the DSP 140 returns PQ set to "FAIL", the "No Tone" state 238 is entered.

[0055] In the "Store Values" state 236, the microcontroller stores five values of gain and slope. FM is set to "Wait." If TIMEOUT reaches 10 seconds while the microcontroller is in "Store Values" 236, it moves to the "No Tone" state 238. In the "No Tone" state 238, the TIMEOUT timer is stopped, and FM is set to "Wait" in order to instruct the DSP 140 to standby. Also, if the LOOP_FLAG variable is set to TRUE, the four signaling LED's (TA, TB, RA, and RB) are flashed in a vertical pattern ("||") to indicate that an off-hook condition existed prior to the attempted auto-alignment and is the most probable cause for not receiving an alignment test signal from the Auto FX 14; otherwise, the LED's are flashed in a horizontal pattern ("==") to indicate that the test signal from the Auto FX 14 was detected, but the level of the received signal was below the -25 dBm threshold required for accurate gain and slope alignment. If the microcontroller is in "No Tone" 238 for more than 10 seconds, or if rotary switch 148 is not set to "AutoAlign" and the auto-alignment sequence was not entered as the result of "Power-On Reset", then "Exit" 230 is entered.

[0056] From the "Store Values" state 236, if all five of the most recent iterative gain and slope values are downloaded from the DSP 140 and loaded into the DAC attenuators 132 and 134 and slope equalizer latch 136 successfully, then the microcontroller 138 returns to the Analyze Tone 234 state. If the PQ response from the DSP 140 indicates that an acceptable gain and slope solution was determined (PQ equal to PASS), then "Analyze Tone" 234 is exited and the "pass" state 240 is entered. In the "pass" state 240, the SLIC 124 is put into a high impedance state and a shorting circuit (not shown) at the metallic interface unit 18 tip 118 and ring 120 leads is activated to ensure that the calibration unit 14 is powered down and reset. Also, the signaling LED's are flashed rapidly, a NEW_VALUES variable is set to "TRUE" (indicates that a gain and slope solution has been determined), and COMMAND is set to "PASS." Finally, the TIMEOUT timer is stopped and FM is set to "TONE ON" in order to instruct the DSP 140 to generate a 0dBm 1kHz signal in both transmit and

receive directions. The 0dBm 1kHz signal, or digital milliwatt, is used as an audible indication of the successful determination of a gain and slope solution.

[0057] Once the microcontroller has been in "pass" 240 for 6ms, the shorting circuit is deactivated and forward battery is restored in order to power up the Auto FX 18 in preparation for receiving the next command. After 1006 milli-seconds in the "pass" state 240 the microcontroller 138 returns to "Send Command" 216. Because COMMAND is now set to "PASS", the command sequence is set to comprise 15 open-closed intervals followed by an inter-sequence interval and another 15 open-closed intervals.

[0058] Fig. 10 illustrates the two command sequences for "Initiate Auto Align" and "Auto Align Passed" respectively. Figure 10a illustrates the signaling sequence 300 for the "Initiate Auto Align" command. When the calibration unit detects this sequence on the tip and ring leads, the calibration unit begins the Auto Align procedure, including transmitting the 1 kHz square wave test tone to the metallic interface unit. The first portion of the signaling sequence 302 comprises 13 open-closed intervals, with each open interval preferably lasting 48ms and each closed interval preferably lasting 150ms. The first open-closed interval 302 is followed by an inter-sequence interval 304, which preferably lasts about one half second. Finally, a second open-closed interval 306 is transmitted, comprising another 13 sets of open and closed intervals of the same duration.

[0059] Fig. 10b illustrates the signaling sequence 308 for the "Auto Align Passed" command. When the calibration unit detects this sequence on the tip and ring leads, the calibration unit acknowledges that the Auto Align process has been completed successfully by turning on it's LED 64 for approximately 30 seconds. The sequence is similar to the "Initiate Auto Align" command, except that the first set of open-closed intervals 310 and the second set of open-closed intervals 312 each comprise 15 sets of open and closed intervals. The inter-sequence interval 314 preferably remains approximately one half second in duration.

[0060] While a preferred embodiment of the present invention has been shown and described, it is to be understood that many changes and modifications may be

made thereto without departing from the spirit and scope of the invention as defined in the appended claims.

100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294